WRM

TCODE – QA32



Press On Execute Button.

RESULT RECORDING





Select the inspection lot and click on “Result”.



Select one by one operations and fill result.





Save the entries.

UD

Select the line and press on “Usage Decision”.



Select the UD Code (Either Accept Or Reject) accordingly.



Press on Inspected Lot Stock tab.



Save it.

After refreshing, line will be disappeared from list.



Monit...	A	Insp. Lot	Material	Plant	Lot Qty	BUn	LT...	ST...	Start Date	End Date	System Status
		400000..	60105578870030	2000	2.020	TO	0	0	19.03.2020	19.03.2020	REL CALC SPRQ
		400000..	60105578870030	2000	2.030	TO	0	0	19.03.2020	19.03.2020	REL CALC SPRQ
		400000..	60105578870030	2000	2.050	TO	0	0	19.03.2020	19.03.2020	REL CALC SPRQ
		400000..	60105578870030	2000	2.060	TO	0	0	19.03.2020	19.03.2020	REL CALC SPRQ
		400000..	60105578870030	2000	2.070	TO	0	0	19.03.2020	19.03.2020	REL CALC SPRQ
		400000..	60105578870030	2000	2.070	TO	0	0	19.03.2020	19.03.2020	REL CALC SPRQ
		400000..	60105578870030	2000	2.070	TO	0	0	19.03.2020	19.03.2020	REL CALC SPRQ
		400000..	60105578870030	2000	2.043	TO	0	0	28.03.2020	28.03.2020	LTCA CALC
		400000..	60105578870030	2000	2.043	TO	0	0	28.03.2020	28.03.2020	LTCA CALC
		400000..	60105578870030	2000	4	TO	0	0	03.04.2020	03.04.2020	REL CALC SPRQ